

# Air for life

### Technical Data Sheet

Flair 225 English



### Contents

1 Delivery	3
1.1 Delivery size	3
2 Version	4
2.1 Technical information	4
2.2 Connections and dimensions	5
2.3 Exploded view of appliance	7
3 Service	8
3.1 Exploded view	8
3.2 Service articles	9
4 Conformity declaration	1
5 ERP values	2
6 Populing 1	1


## 1 Delivery

### 1.1 Delivery size

Before installation of the heat recovery appliance is started, check that it has been supplied in complete and undamaged condition.

The delivery size of the heat recovery appliance type Flair 225 consists of the following components:

- 1. Heat recovery appliance
- 2. Wall mounting bracket consisting of:
  - 1x mounting bracket
  - 2x protective caps
  - 2x rubber strip
  - 2x rubber rings
- 3. Siphon
- 4. Documentation set consisting of:
  - 1x installation instructions
  - 1x occupant's instructions



### 2 Version


#### 2.1 Technical information

Flair 225											
Supply voltage [V/Hz]			230V/50Hz								
Dimensions (w x h x d) [mm]		600 x 650 x 455									
Duct diameter [mm]		ø125									
Ext. diameter condensate disc	harge [mm]	ø32									
Weight [kg]		29									
Filter class		ISO Co	arse 609	% (ISO e	PM1.0 5	0% for t	he air s	upply op	otional)		
Fan setting (factory setting)		(	)	:	1	2		3	3	max	
Factory setting [m³/h]		4	0	5	0	100		150		225	
Permissible resistance of duct system [Pa]		3	8	5	12	20	49	44	111	100	250
Rated power (excl. preheater) [W]		7.9	8.3	8	8.7	13.2	17.3	26.2	37.9	61.5	92.2
Rated current (excl. preheater) [A]		0.10	0.11	0.10	0.10	0.13	0.16	0.22	0.32	0.48	0.70
Max. rated current (incl. preheater on) [A]		3.8									
Rated power preheater [W]			1000								
Cos φ		0.336	0.34	0.357	0.363	0.447	0.460	0.507	0.521	0.522	0.572
Sound power											
Ventilation capacity [m <sup>3</sup> /h]					50	100	100	150	150	225	225
	Static pressure	Static pressure [Pa]		25	25	50	50	100	100	150	
Cound nower level Lu/A)	Casing radiation [dB(A)]			28	31	33.5	38.5	40.5	45.5	47	
Sound power level Lw(A)	Duct "From dwelling' [db(A)]			<30	<34.5	<36.5	44	43	47.5	48.5	
	Duct 'To dwell	ing' [db(	(A)]		43.5	48.5	50.5	55	57.5	62.5	64.5

<sup>\*)</sup> Duct noise including end correction

In practice the value may differ by 1dB(A) through measurement tolerances.






#### Note:


The stated value in the circle is the capacity (in Watt) per fan.

#### 2.2 Connections and dimensions

The Flair appliance is available in a left-hand and right-hand version. With a left-hand version the "warm" connections (from dwelling 3 and to dwelling 1) are on the left-hand side of the appliance; the condensate discharge is then mounted at the right-hand opening below the appliance. With a right-hand version the "warm" connections (1 & 3) are on the right-hand side of the appliance.

#### Left-hand version







All dimensions in millimeters. Diameter of all collars is 125 mm

1	Supply air			
2	Exhaust air			
3	Extract			
4	Outdoor air			
5	Electrical connections			
6a	Siphon connection			
6b	Sealing cap unused condensate discharge connection; do not remove!			
7	Extract air filter			
8	Supply air filter			

#### Right-hand version






All dimensions in millimeters. Diameter of all collars is 125 mm

1	Supply air
2	Exhaust air
3	Extract
4	Outdoor air
5	Electrical connections
6a	Siphon connection
6b	Sealing cap unused condensate discharge connection; do not remove!
7	Extract air filter
8	Supply air filter

### 2.3 Exploded view of appliance



The appliance shown above is a left-hand version: in the case of a right-hand version, the connector of the preheater, bypass valve and the siphon connector are installed in mirror image!					
1	Touchscreen	12	Heat exchanger		
2	USB connector (X13)	13	Motor bypass valve		
3	Service connector	14	Exhaust air filter		
4	LED indicator	15	Bypass valve		
5	Maximum protection preheater	16	Power cable 230 volt		
6	Preheater	17	Relay output (X19) )		
7	Temperature sensor	18	24 volt connector (X18)		
8	Supply filter	19	eBus connector (X17)		
9	Exhaust fan	20	24 volt connector (X16)		
10	Siphon	21	Modbus/ Internalbus connector (X15)		
11	Supply ventilator	22	Multiple switch connector (X14)		

### 3 Service


### 3.1 Exploded view

When ordering parts, in addition to the article code number (see exploded view), please state the heat recovery appliance type, the serial number, the year of production and the name of the part:

**N.B.:** Appliance type, serial number and year of production are stated on the identification plate behind the plastic front panel on the appliance.

Example				
Appliance type	Flair 225			
Serial number	428000220201			
Year of production	2023			
Part	Fan			
Article code	532803			
Quantity	1			

### 3.2 Service articles



No.	Article description	Article code
1	Front panel complete	532799
2	Filters (2 items) ISO Coarse 60%	532811
3	Heat exchanger	532795
4	Fan (1 item)	532803
5	Bypass valve with motor complete	532797
6	Display pcb UBP-2	532752
7	Appliances manufactured <b>before 01-01-2023</b> : Basic pcb UWA2-B + display	532750
,	Appliances manufactured <b>after 01-01-2023</b> : Basic pcb UWA2-B	532966
8	Plus pcb UWA2-E (only applicable with Plus version)	532751
9	Mains plug and cable 230 V *	532756
10	Internal preheater incl. maximum security	532798
11	Temperature sensor NTC 10K	531775
12	Condensation discharge	532762
13	Cable set	532767

<sup>\*</sup> The power cable is fitted with a circuit board connector. When replacing it, always order a replacement mains cable from Brink.

To prevent dangerous situations, a damaged mains connection can only be replaced by a qualified expert.

### 4 Conformity declaration

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Manufacturer: Brink Climate Systems B.V.

Address: Postbus 11

NL-7950 AA, Staphorst, The Netherlands

Product: Flair 225

The product described above complies with the following directives:

◆ 2014/35/EU (OJEU L 96/357; 29-03-2014)

◆ 2014/30/EU (OJEU L 96/79; 29-03-2014)

◆ 2009/125/EU (OJEU L 285/10; 31-10-2009)

◆ 2017/1369/EU (OJEU L 198/1; 28-07-2017)

◆ RoHS 2011/65/EU (OJEU L 174/88; 01-07-2011)

The product described above has been tested according to the following standards:

◆ EN IEC 55014-1: 2021

♦ EN IEC 55014-2: 2021

◆ EN IEC 61000-3-2: 2019 + A1:2021

◆ EN 61000-3-3: 2013 + A1:2019 + A2:2021

◆ EN 60335-1: 2012 + AC:2014 + A11:2014 + A13:2017 + A1:2019 +

A2:2019 + A14:2019 + A15:2021

◆ EN 60335-2-40: 2003 + A11:2004 + A12:2005 +AC:2006 + A1:2006 +

A2:2009 + AC:2010 + A13:2012

◆ EN 62233: 2008 + AC:2008

Staphorst, 07-06-2023

A. Hans Director

# 5 ERP values

Manufactui	rer:	Brink Climate	Brink Climate Systems B.V.					
Model:		Flair 225						
Climate zone	Type of control	SEC Value in kWh/m²/a	SEC Class	Annual electricity consumption (AEC) in kWh	Annual heating saved (AHS) in kWh			
Average	manual	-40,78	Α	258	4655			
	clock control	-41,42	А	237	4667			
	1x sensor (RV/CO <sub>2</sub> /VOC)	-42,62	A+	199	4692			
	2 or more sensors (RV/CO <sub>2</sub> /VOC)	-44,71	A+	135	4741			
Cold	manual	-79,92	A+	795	9107			
	clock control	-80,68	A+	774	9131			
	1x sensor (RV/CO <sub>2</sub> /VOC)	-82,12	A+	736	9179			
	2 or more sensors (RV/CO <sub>2</sub> /VOC)	-84,68	A+	672	9275			
Hot	manual	-15,73	E	213	2105			
	clock control	-16,30	E	192	2111			
	1x sensor (RV/CO <sub>2</sub> /VOC)	-17,37	E	154	2122			
	2 or more sensors (RV/CO <sub>2</sub> /VOC)	-19,19	E	90	2144			
Type of ventilation unit:		Balanced residential ventilation appliance with heat recovery						
Fan:		EC - fan with infinitely variable control						
Type of heat	: exchanger:	Recuperative p	lastic cro	ss-counterflow hea	t exchanger			
Thermal effi	ciency	92 %						
Maximum fl	ow rate:	225 m³/h						
Maximum ra	ated power:	118 W						
Sound powe	r level Lwa:	39 dB(A)						
Reference flo	ow rate:	158 m³/h	·					
Reference p		50 Pa						
•	ver Input (SEL):		0,17 Wh/m³					
Control factor	or:		1.0 in combination with multiple position switch					
		0.000	0.95 in combination with clock control					
		0.85 in combination with 1 sensor						
			0.65 in combination with 2 or more sensors					
Leakage*	Internal	0.70 %						
External		1.80 %						
Position dirty filter indication:		(LED) / on the E Attention! For	On the display of the appliance / on the multiple position switch (LED) / on the Brink Air Control.  Attention! For optimal energy efficiency and a proper operation, a regular filter inspection, cleaning or replacement is					
Internet add	lress for Assembly instructions:		https://www.brinkclimatesystems.nl/support/downloads					
Bypass:	incos io. Addenibly instructions.		Yes, 100% Bypass					
-, pass.	103, 100% bypa	IES, 100/0 DYPASS						

<sup>\*</sup> Measurements executed by TZWL according to the EN 13141-7 standard

Classification from 1 January 2016				
SEC class ("Average climate zone" )	SEC in kWh/m²/a			
A+ (Most efficient)	SEC < -42			
А	-42 ≤ SEC < -34			
В	-34 ≤ SEC < -26			
С	-26 ≤ SEC < -23			
D	-23 ≤ SEC < -20			
G (Least efficient)	-20 ≤ SEC < -10			

# 6 Recycling

#### Recycling

Sustainable materials are used in the manufacture of this appliance. The packaging should be disposed of in a responsible manner and in accordance with governmental regulations.





Wethouder Wassebaliestraat 8, NL-7951SN Staphorst

T: +31 (0) 522 46 99 44

E. info@brinkclimatesystems.nl www.brinkclimatesystems.nl